

DRUMTRACKER[™]
The Complete Cradle to Grave Solution

DrumTracker II[™]

Portable Data Terminal

**Software Installation
Manual**



1. What you will need
 - a. The PDT with all parts/cables
 - b. A computer with a USB cable and the authority to install a new program
 - c. A 120 V outlet nears the above computer
 - d. A working 802.11b wireless network
 - e. The DrumTracker software CAB files (3 files)
2. Unpack PDT and Verify all parts are present
 - a. PDT
 - i. Battery should already be in slot under keyboard
 - b. Cradle (Has a slot for the PDT and one for a spare battery)
 - c. Power converter (heavy black metal box)
 - d. AC cord (has familiar 3-prong plug on one end)
 - e. DC cord (does not have familiar 3-prong plug on one end)
3. Assemble PDT
 - a. Plug DC cord into cradle and then the power converter
 - b. Plug AC cord into converter and then a 120 V wall outlet
 - c. Verify that the battery is in the PDT slot (under keyboard) properly
 - d. Set the PDT into the cradle until the yellow light above the keyboard comes on (flashing OK). It is now charging.
4. Set up installation computer
 - a. Install ActiveSync (current version 4.5 as of June 2007)
<http://www.microsoft.com/windowsmobile/activesync/activesync45.mspx>
 - i. Click on language choice most of the way down the document
 1. e.g. "Worldwide English"
 - ii. Click on "Download ActiveSync without Registration"
 - iii. Click on <Accept and Download> button at bottom
 - iv. Click on <OK> if asked about switching sites
 - v. Click on <Run> when prompted
 - vi. Click on <Install> when prompted
 - vii. Click on <OK> when installation complete
 - viii. Restart if required
 - b. Connect PDT cradle to installation computer
 - i. Use own USB cable from PDT cradle to installation computer
 - c. Explore PDT drive
 - i. Turn on PDT (if not already on)
 - ii. ActiveSync will open
 - iii. ActiveSync wizard will step you through connecting as GUEST
 - iv. Once connected, click on <Explore> in the ActiveSync window.
5. Installing DrumTracker II on the PDT
 - a. Open another Explorer window to see the installation computer's drive
 - b. Verify that you have saved the 3 files on your hard disk or a CD
 - i. The files are:
 1. NETCFv2[1].ppc.armv4.cab
 2. sqlce30.ppc.wce4.armv4.CAB
 3. DepDrums_Deploy.CAB

- ii. You cannot take them straight from an email to the PDT – they must be saved first as they need to be converted for each PDT
 - c. In the ActiveSync-opened Explorer window, Click on <My Windows Device> (or <My Windows Mobile> or similar)
 - d. Using the ActiveSync-opened Explorer window, drag all 3 files from the installation computer's disk to the PDT disk
 - i. ActiveSync will convert the files as they are moved onto the PDT
 - e. Remove the PDT from the cradle
 - f. On the PDT, click on <Start>, <Programs>, <File Explorer>
 - i. Click on the same place where you just dragged the installation files
 - ii. e.g. <My Windows Device> or <My Windows Mobile> or similar
 - iii. Click on NETCFv2[1].ppc.armv4.cab
 - iv. It will ask you if you want to install it, click <Yes>
 - v. The PDT may need to reboot (which it will do automatically)
 - vi. Navigate again using File Explorer to where you saved the CAB files
 - vii. Click on sqlce30.ppc.wce4.armv4.CAB
 - viii. It will ask you if you want to install it, click <Yes>
 - ix. The PDT may need to reboot (which it will do automatically)
 - x. Navigate again using File Explorer to where you saved the CAB files
 - xi. Click on DepDrums_Deploy.CAB
 - xii. If directed, copy updates to the PDT.
See PDT Software Updates Manual.
 - g. Adding DrumTracker II to the Programs list
 - i. TBD
- 6. Connecting the PDT to the wireless network
 - a. On the PDT, click on <Start>, <Programs>, <File Explorer>
 - b. Click on <My Windows Device>, TBD
 - c. TBD
 - d. Verify the PDT has internet access by browsing a web site
 - i. Click on Internet Explorer
 - ii. Click <Favorites>
 - iii. Click on any web page listed
- 7. Starting the DrumTracker II program for the first time
 - a. With the PDT in or out of the cradle, click on the DrumTracker II program icon or name
- 8. Continue with the PDT Program Setup Manual